



2

ENGLISH

ELECTRIC HOT PLATE VT-3705

The electric hot plate is intended for cooking and reheating food.

DESCRIPTION

- 1. Hot plate body
- 2. Hob
- 3. Temperature control
- 4. Pilot light

ATTENTION!

For additional protection it is reasonable to install a residual current device (RCD) with nominal operation current not exceeding 30 mA. To install an RCD, contact a specialist.

SAFETY PRECAUTIONS

Before using the unit, thoroughly read through this instruction manual and keep it for future reference. Use the unit for its intended purposes only, as specified in this manual.

Mishandling the unit can lead to breakage and cause harm to the user or damage to his/her property.

Note: While the first switching-on, the hob (2) is scorched, therefore occurrence of a small amount of smoke or foreign smell is possible, it is normal.

The power cord is equipped with a Type E/F two-pin plug with a pair of earth contacts; connect it to an outlet having a reliable earth contact.

To avoid fire, do not use adaptors for plugging the unit in.

To avoid mains overloading, do not switch on several electrical appliances with high power consumption at a time.

Place the unit on a flat stable heat-resistant surface with free access to the mains socket.

Be careful! The hob (2) surface and the hot plate body (1) heat up during the operation and remain hot for some time after the unit is unplugged.

ATTENTION!

To avoid damaging the unit do not switch it on without cookware placed on the hob (2) and do not use the electric hot plate for heating of rooms.

Note: To reach the best contact with the hob, choose cookware with a flat bottom matching the hob diameter.

CLEANING AND MAINTENANCE

Never immerse the unit into water or other liquids.

• Clean the electric hot plate regularly.

• Set the temperature control to the position "●●●".

• Unplug the unit from the mains and let it cool down.

• Do not touch the power plug with wet hands.

• Do not use the unit near the kitchen sink, do not expose it to moisture.

• To avoid the risk of electric shock or fire, do not immerse the unit body, the power cord and the power plug into water or any other liquids.

• If the unit is dropped into water:

- do not touch the water;

- unplug the unit immediately, only after that you may take the unit out of the water;

- apply to an authorized service center for testing or repairing the unit.

• Be careful: the hob and the hot plate body heat up strongly during operation, do not touch hot surfaces.

• Do not move the unit until it cools down completely.

• Do not allow children to use the unit as a toy.

• For children safety reasons do not leave polyethylene bags used as a packaging unattended.

Attention! Do not allow children to play with polyethylene bags or packaging film. **Danger of suffocation!**

This unit is not intended to be used by children.

• Close supervision is necessary when children or people with disabilities are near the operating unit.

• Do not allow children to touch the hot plate body, the power cord or the power plug during operation of the unit.

• During the unit operation and breaks between operation cycles, place the unit out of reach of children.

• The unit is not intended for usage by physically or mentally disabled persons (including children) by persons lacking experience or knowledge if they are not under supervision of a person who is responsible for their safety or if they are not instructed by this person on the usage of the unit.

The waste generated during the disposal of the unit is subject to mandatory collection and consequent disposal in the prescribed manner.

• Do not use the unit if the power cord or plug is damaged.

• Do not attempt to repair the unit by yourself. Do not disassemble the unit, if any malfunction is detected or after it was dropped, unplug the unit and apply to any authorized service center from the contact address listed in the warranty certificate and on the website www.vitek.ru.

• For further information about recycling of this product apply to a local municipal administration, a disposal service or to the shop where you purchased this product.

• Do not dismantle the unit, if any malfunction is detected or after it was dropped, unplug the unit and apply to any authorized service center from the contact address listed in the warranty certificate and on the website www.vitek.ru.

• Do not use the unit if the power cord or plug is damaged.

• Do not attempt to repair the unit by yourself. Do not disassemble the unit, if any malfunction is detected or after it was dropped, unplug the unit and apply to any authorized service center from the contact address listed in the warranty certificate and on the website www.vitek.ru.

• Do not use the unit if the power cord or plug is damaged.

• Do not attempt to repair the unit by yourself. Do not disassemble the unit, if any malfunction is detected or after it was dropped, unplug the unit and apply to any authorized service center from the contact address listed in the warranty certificate and on the website www.vitek.ru.

• Do not use the unit if the power cord or plug is damaged.

• Do not attempt to repair the unit by yourself. Do not disassemble the unit, if any malfunction is detected or after it was dropped, unplug the unit and apply to any authorized service center from the contact address listed in the warranty certificate and on the website www.vitek.ru.

• Do not use the unit if the power cord or plug is damaged.

• Do not attempt to repair the unit by yourself. Do not disassemble the unit, if any malfunction is detected or after it was dropped, unplug the unit and apply to any authorized service center from the contact address listed in the warranty certificate and on the website www.vitek.ru.

• Do not use the unit if the power cord or plug is damaged.

• Do not attempt to repair the unit by yourself. Do not disassemble the unit, if any malfunction is detected or after it was dropped, unplug the unit and apply to any authorized service center from the contact address listed in the warranty certificate and on the website www.vitek.ru.

• Do not use the unit if the power cord or plug is damaged.

• Do not attempt to repair the unit by yourself. Do not disassemble the unit, if any malfunction is detected or after it was dropped, unplug the unit and apply to any authorized service center from the contact address listed in the warranty certificate and on the website www.vitek.ru.

• Do not use the unit if the power cord or plug is damaged.

• Do not attempt to repair the unit by yourself. Do not disassemble the unit, if any malfunction is detected or after it was dropped, unplug the unit and apply to any authorized service center from the contact address listed in the warranty certificate and on the website www.vitek.ru.

• Do not use the unit if the power cord or plug is damaged.

• Do not attempt to repair the unit by yourself. Do not disassemble the unit, if any malfunction is detected or after it was dropped, unplug the unit and apply to any authorized service center from the contact address listed in the warranty certificate and on the website www.vitek.ru.

• Do not use the unit if the power cord or plug is damaged.

• Do not attempt to repair the unit by yourself. Do not disassemble the unit, if any malfunction is detected or after it was dropped, unplug the unit and apply to any authorized service center from the contact address listed in the warranty certificate and on the website www.vitek.ru.

• Do not use the unit if the power cord or plug is damaged.

• Do not attempt to repair the unit by yourself. Do not disassemble the unit, if any malfunction is detected or after it was dropped, unplug the unit and apply to any authorized service center from the contact address listed in the warranty certificate and on the website www.vitek.ru.

• Do not use the unit if the power cord or plug is damaged.

• Do not attempt to repair the unit by yourself. Do not disassemble the unit, if any malfunction is detected or after it was dropped, unplug the unit and apply to any authorized service center from the contact address listed in the warranty certificate and on the website www.vitek.ru.

• Do not use the unit if the power cord or plug is damaged.

• Do not attempt to repair the unit by yourself. Do not disassemble the unit, if any malfunction is detected or after it was dropped, unplug the unit and apply to any authorized service center from the contact address listed in the warranty certificate and on the website www.vitek.ru.

• Do not use the unit if the power cord or plug is damaged.

• Do not attempt to repair the unit by yourself. Do not disassemble the unit, if any malfunction is detected or after it was dropped, unplug the unit and apply to any authorized service center from the contact address listed in the warranty certificate and on the website www.vitek.ru.

• Do not use the unit if the power cord or plug is damaged.

• Do not attempt to repair the unit by yourself. Do not disassemble the unit, if any malfunction is detected or after it was dropped, unplug the unit and apply to any authorized service center from the contact address listed in the warranty certificate and on the website www.vitek.ru.

• Do not use the unit if the power cord or plug is damaged.

• Do not attempt to repair the unit by yourself. Do not disassemble the unit, if any malfunction is detected or after it was dropped, unplug the unit and apply to any authorized service center from the contact address listed in the warranty certificate and on the website www.vitek.ru.

• Do not use the unit if the power cord or plug is damaged.

• Do not attempt to repair the unit by yourself. Do not disassemble the unit, if any malfunction is detected or after it was dropped, unplug the unit and apply to any authorized service center from the contact address listed in the warranty certificate and on the website www.vitek.ru.

• Do not use the unit if the power cord or plug is damaged.

• Do not attempt to repair the unit by yourself. Do not disassemble the unit, if any malfunction is detected or after it was dropped, unplug the unit and apply to any authorized service center from the contact address listed in the warranty certificate and on the website www.vitek.ru.

• Do not use the unit if the power cord or plug is damaged.

• Do not attempt to repair the unit by yourself. Do not disassemble the unit, if any malfunction is detected or after it was dropped, unplug the unit and apply to any authorized service center from the contact address listed in the warranty certificate and on the website www.vitek.ru.

• Do not use the unit if the power cord or plug is damaged.

• Do not attempt to repair the unit by yourself. Do not disassemble the unit, if any malfunction is detected or after it was dropped, unplug the unit and apply to any authorized service center from the contact address listed in the warranty certificate and on the website www.vitek.ru.

• Do not use the unit if the power cord or plug is damaged.

• Do not attempt to repair the unit by yourself. Do not disassemble the unit, if any malfunction is detected or after it was dropped, unplug the unit and apply to any authorized service center from the contact address listed in the warranty certificate and on the website www.vitek.ru.

• Do not use the unit if the power cord or plug is damaged.

• Do not attempt to repair the unit by yourself. Do not disassemble the unit, if any malfunction is detected or after it was dropped, unplug the unit and apply to any authorized service center from the contact address listed in the warranty certificate and on the website www.vitek.ru.

• Do not use the unit if the power cord or plug is damaged.

• Do not attempt to repair the unit by yourself. Do not disassemble the unit, if any malfunction is detected or after it was dropped, unplug the unit and apply to any authorized service center from the contact address listed in the warranty certificate and on the website www.vitek.ru.

• Do not use the unit if the power cord or plug is damaged.

• Do not attempt to repair the unit by yourself. Do not disassemble the unit, if any malfunction is detected or after it was dropped, unplug the unit and apply to any authorized service center from the contact address listed in the warranty certificate and on the website www.vitek.ru.

• Do not use the unit if the power cord or plug is damaged.

• Do not attempt to repair the unit by yourself. Do not disassemble the unit, if any malfunction is detected or after it was dropped, unplug the unit and apply to any authorized service center from the contact address listed in the warranty certificate and on the website www.vitek.ru.

• Do not use the unit if the power cord or plug is damaged.

• Do not attempt to repair the unit by yourself. Do not disassemble the unit, if any malfunction is detected or after it was dropped, unplug the unit and apply to any authorized service center from the contact address listed in the warranty certificate and on the website www.vitek.ru.

• Do not use the unit if the power cord or plug is damaged.

• Do not attempt to repair the unit by yourself. Do not disassemble the unit, if any malfunction is detected or after it was dropped, unplug the unit and apply to any authorized service center from the contact address listed in the warranty certificate and on the website www.vitek.ru.

• Do not use the unit if the power cord or plug is damaged.

• Do not attempt to repair the unit by yourself. Do not disassemble the unit, if any malfunction is detected or after it was dropped, unplug the unit and apply to any authorized service center from the contact address listed in the warranty certificate and on the website www.vitek.ru.

• Do not use the unit if the power cord or plug is damaged.

• Do not attempt to repair the unit by yourself. Do not disassemble the unit, if any malfunction is detected or after it was dropped, unplug the unit and apply to any authorized service center from the contact address listed in the warranty certificate and on the website www.vitek.ru.

• Do not use the unit if the power cord or plug is damaged.

• Do not attempt to repair the unit by yourself. Do not disassemble the unit, if any malfunction is detected or after it was dropped, unplug the unit and apply to any authorized service center from the contact address listed in the warranty certificate and on the website www.vitek.ru.

• Do not use the unit if the power cord or plug is damaged.

• Do not attempt to repair the unit by yourself. Do not disassemble the unit, if any malfunction is detected or after it was dropped, unplug the unit and apply to any authorized service center from the contact address listed in the warranty certificate and on the website www.vitek.ru.

• Do not use the unit if the power cord or plug is damaged.

• Do not attempt to repair the unit by yourself. Do not disassemble the unit, if any malfunction is detected or after it was dropped, unplug the unit and apply to any authorized service center from the contact address listed in the warranty certificate and on the website www.vitek.ru.

• Do not use the unit if the power cord or plug is damaged.

• Do not attempt to repair the unit by yourself. Do not disassemble the unit, if any malfunction is detected or after it was dropped, unplug the unit and apply to any authorized service center from the contact address listed in the warranty certificate and on the website www.vitek.ru.

• Do not use the unit if the power cord or plug is damaged.

• Do not attempt to repair the unit by yourself. Do not disassemble the unit, if any malfunction is detected or after it was dropped, unplug the unit and apply to any authorized service center from the contact address listed in the warranty certificate and on the website www.vitek.ru.

• Do not use the unit if the power cord or plug is damaged.

• Do not attempt to repair the unit by yourself. Do not disassemble the unit, if any malfunction is detected or after it was dropped, unplug the unit and apply to any authorized service center from the contact address listed in the warranty certificate and on the website <a

УКРАЇНСЬКА

ПЛІТКА ЕЛЕКТРИЧНА VT-3705

Електрична плитка призначена для розігрівання та приготування продуктів харчування.

- ОПИС**
 1. Корпус плитки
 2. Конфорка
 3. Регулятор температури
 4. Світловий індикатор

УВАГА!

Для додаткового захисту у колі живлення доцільно встановити пристрій захисного вимкнення (ПЗВ) з номінальним струмом спрацювання, що не перевищує 30 мА. Для установлення ПЗВ зверніться до фахівця.

ЗАХОДИ БЕЗПЕКИ

Перед початком експлуатації уважно прочитайте інструкцію з експлуатації та обережно! Для використання цієї плитки будь-якими засобами, як вказано у цій інструкції.

Неправильне використання пристрію може привести до його поломки, завдання шкоди користувачеві або його майнові.

- Перед першим використанням плитки видаліть всі пакувальні матеріали та реклами належності, що заважають нормальній роботі пристрію.
- Переконайтесь, що напруга у мережі відповідає робочій напрузі плитки.
- Перевірте, щоб регулятор температури (3) знаходився у положенні .

ВІКОРІСТАННЯ

- Перед увімкненням, переконайтесь у відсутності вологи та залишків ліків на конфорції (2).
- Розміщіть посуд по центру конфорки (2).
- Вставте вилку мережевого шнура у розетку.
- Виберіть режим роботи плитки за допомогою регулятора температур (3):

• – плитка вимкнена;

• – максимальна температура нагріву.

Примітка: При першому вимкненні конфорка (2) обгоряє, тому можливі з'явлення невеликої кількості диму або стороннього запаху – це нормальне явище.

Щоб уникнути вимкнення пристрію, вимкніть його без надійного контакту заземлення.

- Щоб уникнути перевантаження електричної мережі, не вимкніть одночасно декілька пристріїв з великою споживчою потужністю.
- Розміщіть пристрій на рівній, стійкий, теплостійкій поверхні так, щоб доступ до мережевої розетки був вільним.
- Використовуйте пристрій в місцях з добрею вентиляцією. Щоб уникнути загорання, в жодному разі не розміщуйте пристрій поряд з занавісками або шторами та не накривайте його під час роботи.

• Не використовуйте пристрій поза приміщеннями.

• Не використовуйте електроплиту для обігрівання приміщень.

• Забороняється використання пристрію у приміщеннях, де зберігаються або використовуються легкозаймані речовини.

• Не використовуйте пристрій поблизу газових плит та обігрівачів, які не ставлять його на гарячі поверхні.

• Не допускайте звисання мережевого шнура зі стола, а також його контакту з гарячими поверхнями або гарячими окраїнами дверок або корпусу пристрію.

• Під час використання мережевого шнура з електричної розетки не лягніть, що шнур, а тримайте за вилку руками.

• Не беріться за вилку мережевого шнура мокрими руками.

• Не користуйтесь пристрієм в безпосередній близькості від кухонної пароварки, ні піддавайте її пологи.

• Щоб уникнути ураження електричним струмом або займання, не занурюйте корпус пристрію, мережевий шнур та вилку мережевого шнура з воду або будь-які інші рідини.

• Якщо пристрій вінав у воді:
 – не торкайтесь води;
 – негайно витягніть вилку мережевого шнура з електричної розетки, і лише після цього можна дистанційно вимкнути пристрій;

• Зберігайте мережевий шнур та носите його центром для огляду або ремонту пристрію.

• Будьте обережні: під час роботи конфорка та корпус сильно нагріваються, не торкайтесь гарячих поверхонь.

• Не переміщайте пристрій, поки він повістє не остигне.

• Не дозволяйте дітям використовувати пристрій як іграшки.

• Змірювань безпеки дітей не залишайте польотіленовими пакетами, що використовуються як упаковка, без нагадувань.

Увага! Не дозволяйте дітям грати з польотіленовими пакетами або пакувальною плюскою. **Небезпека задушування!**

• Цей пристрій не призначений для використання дітьми.

• Будьте особливо уважні, якщо поблизу від пристрію знаходиться діті або особи з обмеженими можливостями.

• Не дозволяйте дітям торкатися корпусу моторного блоку, мережевого шнура та вилки мережевого шнура під час роботи пристрію.

• Під час роботи та після роботи між робочими циклами розміщайте пристрій у місцях, недоступних для дітей.

• Пристрій не призначений для використання під час сну.

• Установіть регулятор температури у положення .

• Вимкніть пристрій з електричної мережі, вийнявши вилку мережевого шнура з розетки, та дайте пристрію остигнути.

• При цінній використанні м'які, неабразивні м'які засоби, нанесені на губку або на м'яку тканину, не користуйтесь абразивними м'якими засобами.

• Щоб уникнути занурення корпусу пристрію, мережевий шнур та вилку мережевого шнура з воду або будь-які інші рідини.

• Якщо пристрій вінав у воді:
 – не торкайтесь води;

– негайно витягніть вилку мережевого шнура з електричної розетки, і лише після цього можна дистанційно вимкнути пристрій;

• Зберігайте мережевий шнур та носите його центром для огляду або ремонту пристрію.

• Будьте обережні: під час роботи конфорка та корпус сильно нагріваються, не торкайтесь гарячих поверхонь.

• Не переміщайте пристрій, поки він повістє не остигне.

• Не дозволяйте дітям використовувати пристрій як іграшки.

• Змірювань безпеки дітей не залишайте польотіленовими пакетами, що використовуються як упаковка, без нагадувань.

• Щоб уникнути пошкодження, перевозьте пристрій лише у заводській упаковці.

• Зберігайте пристрій у місцях, недоступних для дітей та людей з обмеженими можливостями.

ПРИСТРІЙ ПРИЗНАЧЕНИЙ ТІЛЬКИ ДЛЯ ПОБУТОВОГО ВИКОРИСТАННЯ У ХУЛІЛОВИХ ПРИМІЩЕННЯХ, ЗАБОРОНЯЄТЬСЯ КОМЕРЦІЙНЕ ВИКОРИСТАННЯ НА ВИКОРИСТАННЯ ПРИСТРОЮ У ВІРОВІЧНИХ ЗОНАХ ТА РОБОЧИХ ПРИМІЩЕННЯХ.

Термін служби пристрію – 3 роки

Гарантія

Докладні умови гарантії можна отримати в дилера, що продає дану апаратуру. При пред'явленні будь-якої претензії протягом терміну дії даної гарантії варто пред'явити чек або квитанцію про покупку.

• Не використовуйте пристрій в місцях з підвищеною вологістю, а також поблизу легкозайманістю предметів та речовин.

• Для правильного функціонування пристрію необхідна хороша вентиляція, забезпечте вільний простір не менше 10-15 см навколо електроплитки.

Даний продукт відповідає вимогам Директиви 2014/30/EU щодо електромагнітної сумісності та Директиви 2014/35/EU щодо низьковольтного обладнання.

КЫРГЫЗ

ЭЛЕКТР МЕШ VT-3705

Электр меш азық-түлкүтердү жылыту жана бышыру учун арналған.

СЫПТАМА

1. Мештін корпусу
2. Конфорка
3. Температуралың жәндегүчү
4. Жарық индикатору

КӨНҮЛ БУРУНДЫ!

Кошучу короғанда учун электр тармағында потенциалду шииткенде 30 мА ашишбапан корол өнерчүрүш аспалы (КВА) орноттушы маңыздырылған.

Түзмекті тұрау амес пайдалансанда, ал тез бузулуп, сизге же жаңынан шалғандағанда жаңынан.

Түзмекті тұрау амес пайдалансанда, ал тез бузулуп, сизге же жаңынан.

Түзмекті тұрау амес пайдалансанда, ал тез бузулуп, сизге же жаңынан.

Түзмекті тұрау амес пайдалансанда, ал тез бузулуп, сизге же жаңынан.

Түзмекті тұрау амес пайдалансанда, ал тез бузулуп, сизге же жаңынан.

Түзмекті тұрау амес пайдалансанда, ал тез бузулуп, сизге же жаңынан.

Түзмекті тұрау амес пайдалансанда, ал тез бузулуп, сизге же жаңынан.

Түзмекті тұрау амес пайдалансанда, ал тез бузулуп, сизге же жаңынан.

Түзмекті тұрау амес пайдалансанда, ал тез бузулуп, сизге же жаңынан.

Түзмекті тұрау амес пайдалансанда, ал тез бузулуп, сизге же жаңынан.

Түзмекті тұрау амес пайдалансанда, ал тез бузулуп, сизге же жаңынан.

Түзмекті тұрау амес пайдалансанда, ал тез бузулуп, сизге же жаңынан.

Түзмекті тұрау амес пайдалансанда, ал тез бузулуп, сизге же жаңынан.

Түзмекті тұрау амес пайдалансанда, ал тез бузулуп, сизге же жаңынан.

Түзмекті тұрау амес пайдалансанда, ал тез бузулуп, сизге же жаңынан.

Түзмекті тұрау амес пайдалансанда, ал тез бузулуп, сизге же жаңынан.

Түзмекті тұрау амес пайдалансанда, ал тез бузулуп, сизге же жаңынан.

Түзмекті тұрау амес пайдалансанда, ал тез бузулуп, сизге же жаңынан.

Түзмекті тұрау амес пайдалансанда, ал тез бузулуп, сизге же жаңынан.

Түзмекті тұрау амес пайдалансанда, ал тез бузулуп, сизге же жаңынан.

Түзмекті тұрау амес пайдалансанда, ал тез бузулуп, сизге же жаңынан.

Түзмекті тұрау амес пайдалансанда, ал тез бузулуп, сизге же жаңынан.

Түзмекті тұрау амес пайдалансанда, ал тез бузулуп, сизге же жаңынан.

Түзмекті тұрау амес пайдалансанда, ал тез бузулуп, сизге же жаңынан.

Түзмекті тұрау амес пайдалансанда, ал тез бузулуп, сизге же жаңынан.

Түзмекті тұрау амес пайдалансанда, ал тез бузулуп, сизге же жаңынан.

Түзмекті тұрау амес пайдалансанда, ал тез бузулуп, сизге же жаңынан.

Түзмекті тұрау амес пайдалансанда, ал тез бузулуп, сизге же жаңынан.

Түзмекті тұрау амес пайдалансанда, ал тез бузулуп, сизге же жаңынан.

Түзмекті тұрау амес пайдалансанда, ал тез бузулуп, сизге же жаңынан.