F

Cassette

Skullcandy USER GUIDE

Pairing Mode *Off Mode

Pair New Device *off Mode
Coupler Nouvel Appareil *mode Off
Vincular Nuevo Dispositivo *modo Apagado
Acopoja Nuovo Dispositivo *modalità Spento
Empareilhar Novo Dispositivo *modo Desligado
Mit Neuem Gerät Koppeln *ausgeschaltetes Zustand
Nieuw Apparaat Pairen *uitmode
Pardan Ny Enhet *läget Tillstand
Muodosta Uusi Laitepari *off-tila
Sammenkoble Ny Enhet *av-modus
Para Ny Enhet *av-läge
Сопряжение Нового Устройства *выключенное Режиме
配对新设备 *关机模式
新しいデバイスをペアリング *オフモード
*새 기기 짝맞추기 *끄기 모드
*جهاز إقران جديد *وضع الإيقاف

Pair New Device *"Cassette"

Pairing Mode
Mode Couplage
Modo De Vinculación
Modalità Di Accoppiamento
Modo Emparelhamento
Koppelmodus
Paarmodus
Pardannelsestilstand
Laitepariin Muodostamilla
Sammenkoblingsmodus
Parningsläge
Режим Сопряжения
配对模式
ペアリングモード
페어링 모드
وضع الإقران

Power - On

Power - On
On
Encendido
Accensione
Ligar
Ein
Aan
Tænd
Virta Päälle
Strøm Av
Ström Av
Включить
开机
ペアリングモード
전원 켜기
التشغيل

Power - Off

Power - Off
Off
Apagado
Spegnimento
Desligar
Aus
Uitzetting
Skik For Strøm
Virta Pääle/pois
På
På
выключить Питание
关机
電源 - Off
끄기
إيقاف التشغيل

Play/Pause

Play/pause
Lecture/pause
Reproducir/pausar
Riproduzione/pausa
Reproduzir/colocar Em Pausa
Wiedergabe/pause
Afspelen/pauzeren
Afspil/pause
Toisto/tauko
Spill/pause
Spela Upp/pausa
Воспроизведение/пауза
播放/暂停
再生 / 一時停止
재생/일시 정지
تشغيل/إيقاف مؤقت

Volume Up

Volume Up
Volume +
Subir Volumen
Aumento Volume
Aumentar O Volume
Lautstärke Erhöhen
Volume Omhoog
Skru Op For Lydstyrken
Äänenvoimakkuuden Lisäys
Volum Opp
Öka Volymen
Увеличение Громкости
音量增大
音量を上げる
볼륨 높이기
رفع مستوى الصوت

Volume Down

Volume Down
Volume -
Bajar Volumen
Riduzione Volume
Diminuir O Volume
Lautstärke Senken
Volume Omlaag
Skru Ned For Lydstyrken
Äänenvoimakkuuden Vähennys
Volum Ned
Sänka Volymen
Уменьшение Громкости
音量减小
音量を下げる
볼륨 낮추기
خفض مستوى الصوت

Track Forward

Track Forward
Piste Suivante
Adelantar
Brano Successivo
Faixa Seguinte
Nächster Titel
Volgend Nummer
Skift Til Næste Musiknummer
Kelius Eteenpäin
Neste Spor
Nästa Ljudspår
Переключение На 1 Трек Вперед
下一曲目
次のトラックを再生する
다음 트랙으로
مسار التالي

Track Back

Track Back
Piste Précédente
Retroceder
Brano Precedente
Faixa Anterior
Vorangehender Titel
Vorig Nummer
Musikrummer Tilbage
Kelius Taaksepäin
Forige Spor
Byta Till Föregående Spår
Переключение На 1 Трек Назад
上一曲目
前のトラックを再生する
이전 트랙으로
مسار السابق

Answer/End

Answer/end
Répondre/fin
Responder/colgar
Risposta/fine
Atender/desligar
Ennimmen/beenden
Besvar/afslut
Vastaus/lopetus
Svar/avslutt
Svara/lägg På
Ответить/закончить
接听/结束
応答 / 終了
전화 받기/끊기
الإجابة

Activate Assistant

Activate Voice Assistant
Activer l'assistant vocal
Activar el asistente de voz
Attivare assistente vocale
Ativar o assistente de voz
Sprachassistenten aktivieren
Stemhulp activeren
Aktivér talestøtte
Aktivoi äänityöpari
Aktiver taleassistent
Aktivera röstassistent
Активировать голосовой помощник
激活语音助理
ボイスアシスタントをアクティベートする
음성 인식기 동화
تنشيط المساعد الصوتي

Charge

Charge
Charger
Cargar
Carica
Carregar
Aufladen
Opladen
Oplad
Lataus
Lading
Ladda
Зарядка
充电
充電
충전
الشحن

Questions Visit: www.skullcandy.com
Si vous avez des questions visitez sur:www.skullcandy.com
Si tienes dudas, visita: www.skullcandy.com
Domande Visitare il sito: www.skullcandy.com
Fazer perguntas: www.skullcandy.com
Fragen Besuch: www.skullcandy.com
Voor vragen bezoek: www.skullcandy.com
For spørgsmål se: www.skullcandy.com
Vastauksia löytyy: www.skullcandy.com
For spørsmål, besøk: www.skullcandy.com
Vid frågor, besök: www.skullcandy.com
Если у вас возникнут вопросы, посетите: www.skullcandy.com
如有问题请访问：www.skullcandy.com
質問がある場合はこちらをご覧ください：www.skullcandy.com
질문 방문: www.skullcandy.com
www.skullcandy.com: إذا كنت لديك أي أسئلة، فيرجى زيارة

For best quality avoid storing product in conditions above 100 degrees.
Pour assurer la meilleure qualité, évitez de garder aux températures qui dépassent 37,7 °C degrés.
Evite guardar el producto en temperaturas por encima de los 37,7 grados para asegurar su máxima calidad.
Per avere la migliore qualità evitare di conservare il prodotto in condizioni che superano i 37,7 gradi.
Para obter a melhor qualidade, evita guardar o produto em condições superiores a 37,7 graus.
Um die bestmögliche Qualität zu gewährleisten, Produkt nicht über 37,7 °C lagern.
Om de kwaliteit van dit product optimaal te houden, mag het niet bij temperaturen boven 37,7 °C worden opgeslagen.
For at opnå den bedste kvalitet, undgå at opbevare produktet under forhold over 37,7°C.
Parhaan laadun takaamiseksi välttä tuotteen säilyttämistä yli 37,7 asteen lämpötilassa.
For optimal kvalitet bør du unngå å oppbevare produktet i temperaturer over 37,7 grader.
För bästa kvalitet, undvik förvaring över 37,7 grader.
Для наилучшего качества избегайте хранения продукта в условиях выше 37,7 градусов.
为了确保最佳音质，请免将产品置于高于37.7摄氏度的环境之中。
最高の品質を保持するため、37.7 °C 以上の条件で製品を保管しないでください。
최상의 품질을 위해 제품을 37.7도 이상에 보관하지 마세요.
لأفضل جودة، تجنب تخزين المنتج في درجات فوق 37,7 درجة مئوية.

Americas
Skullcandy, Inc.
6301 N Landmark Dr.
Park City, UT 84098, U.S.A.
Skullcandy.com

Canada
Skullcandy Canada ULC
329 Railway St. Unit 205,
Vancouver, BC, V6A 1A4
Canada
Skullcandy.ca

Europe
Skullcandy Europe BV
Postbus 425
5500AK Veldhoven
Nederland
Skullcandy.eu

México
Skullcandy Mexico S de RL de CV
Aristoteles 218
Polanco IV Seccion, Miguel Hidalgo
11550, México City, México
Skullcandy.mx

Japan日本
Skullcandy Japan合同会社
〒150-0001 東京都渋谷区神宮前
5 - 17 - 11 パークサイド一ツキ2階
Skullcandy Japanカスタマーサービス
商品についてのお問い合わせはこちら
Skullcandy.jp

BACK

FI
Skullcandy 2 Year Global Warranty
Warranty: Skullcandy products are covered by a 2 year warranty. If a product works fine, but you feel it is not performing as you expected, contact customer service. Do not return product to your place of purchase. Contact customer service first. Skullcandy products are warranted to be free of defects in materials and workmanship for a period of 2 years. Warranty does not cover normal wear and tear, misuse, abuse, or modification of the product. Warranty does not cover consumable parts such as earpads, batteries, and any product purchased or used outside of the EU, Canada, or United States. Warranty does not cover products purchased from unauthorized third parties. Warranty only covers the original purchaser of the product. Warranty is void if product is used for commercial purposes. Warranty is void if product is used with any product not manufactured or approved by Skullcandy. Warranty is void if product is used in any way that violates any local, state, or federal law, regulation, or ordinance. Warranty is void if product is used in any way that violates the terms of Skullcandy's Terms of Service. Warranty is void if product is used in any way that violates the terms of any third party agreement. Warranty is void if product is used in any way that violates the terms of any third party agreement. Warranty is void if product is used in any way that violates the terms of any third party agreement