REDRAGON

FIZZ RAINBOW
MECHANICAL GAMING KEYBOARD

Please scan here to download user manual

Mechanical Gaming Keyboard Operating Instructions

US UK

Dear user

Thank you for you choosing REDRAGON Brand, to protect your rights and for better customer service, we ask that you note our warranty rules.

1. Within guaranty period, repair is guaranteed for failure due to electrical circuit problems. Man-made damages, such as disassembly, hard impacts, submersion into water, plugging into improper current or voltage, and damage caused by natural disasters such as fire, flood, or earthquake are not included.
2. Consumable parts (such as foot stick) and spare parts replacement are no included in our warranty.

OS support

Windows XP/Vista/Win7/Win8/Win10

Key Function Introduction

FN1 key work with other keys

1. FN1+<Esc>=`~
2. FN1+<1!~0)>= F1~F10
3. FN1+<-_>=F11
4. FN1+<+=>=F12
5. FN1+<A>=←
6. FN1+<S>=↓
7. FN1+<D>=→
8. FN1+<W>=↑
9. FN1+<P>=PRTSC
10. FN1+<[{>=HOME
11. FN1+<]}>=END
12. FN1+<;:>=PGUP
13. FN1+<'">=PGDN
14. FN1+(.>)=INSERT
15. FN1+</?>=DELETE

Fn2 key work with other keys

1. FN2+"9" =18 Backlighting modes switchable
2. FN2+ "0": Turn off backlighting
3. FN2+ "-": Brightness - ,total 5 levels
4. FN2+ "+":Brightness+,total 5 levels
5. FN+WIN: Lock Windows key, press it again to unlock
6. FN2+<Esc >: Press and hold for 3 seconds, Back to factory setting

Macro recording for lighting recording in different game

1. Press FN2+ "Backspace",CAPS key twickle slowly to indicate keyboard is ready for recording.
2. Press again FN2+ "Backspace" to start record,CAPS key twickle quickly, press the desired key to record, max to 64 keys or 30 seconds, press FN2+ "Backspace" to save and quit,preset macro keys will be light on Green.
3. Delete all macro: press and hold FN2+ "Backspace" for 5 seconds to delete all macro.

FAQ

1. If the keyboard doesn't respond, please check if the keyboards USB cable is correctly inserted into the corresponding USB port on the computer, or try another USB port on the computer.
2. If you spill liquid on the keyboard, please unplug the keyboards USB cable from the computer immediately. Wipe off excess liquid and put the keyboard in a warm and ventilated place. Make sure the keyboard is dried naturally before the next use

REDRAGON QUALITY ASSURED

REDRAGON

FIZZ RAINBOW
MECHANICAL GAMING KEYBOARD

Please scan here to download user manual

Mechanical Gaming Keyboard Operating Instructions

PT

Prezado usuário,

Obrigado por escolher a marca REDRAGON . Para proteger seus direitos e oferecer um melhor atendimento ao cliente, pedimos que você observe as regras da nossa garantia.

1. Dentro do período da garantia, os reparos são garantidos nos casos de falha devido a problemas no circuito elétrico. Danos causados pela desmontagem, por impactos violentos, imersão em água, ligação em correntes ou voltagens incorretas e danos causados por desastres naturais, como incêndios, inundações ou terremotos, não estão incluídos.
2. Peças que sofrem desgaste (como pés) e a substituição de peças avulsas não estão incluídas em nossa garantia.

Compatibilidade com OS

Windows XP/Vista/Win 7/Win 8/Win 10

Apresentação das funções das teclas

A tecla FN1 funciona combinada com as outras teclas

1.FN1 + <Esc>=`~
2. FN1 + <1!~0)> = F1 ~ F10
3. FN1 + <-_> = F11
4. FN1 + <+=> = F12
5. FN1 + <A> = ←
6. FN1 + <S> = ↓
7. FN1 + <D> = →
8. FN1 + <W> = ↑
9. FN1 + <P> = PRTSC
10. FN1 + <[{> = HOME
11. FN1 + <]}> = END
12. FN1 + <;:> = PGUP
13. FN1 + <'"> = PGDN
14. FN1 + (.>) = INSERT
15. FN1 + </?> = DELETE

A tecla FN2 funciona combinada com as outras teclas

1. FN2 + "9" = 18 modos de iluminação de fundo
2. FN2 + "0": Desligar iluminação de fundo
3. FN2+ "-": Intensidade - total de cinco níveis
4. FN2 + "+" : Intensidade - total de cinco níveis
5. FN + WIN: Bloquear a tecla Windows, pressione novamente para desbloquear.
6. FN2 + <Esc> : Pressione e segure por três segundos para voltar às configurações de fábrica

Gravação de macro para a gravação da iluminação em jogos diferentes

1. Pressione FN2 + "Backspace" e a tecla CAPS piscará lentamente, indicando que está pronta para a gravação.
2. Pressione FN2 + "Backspace" novamente para iniciar a gravação, a tecla CAPS piscará rapidamente. Pressione as teclas que deseja gravar, no máximo 64 ou 30 segundos. Pressione FN2 + "Backspace" para salvar e sair da definição das teclas macro. As teclas macro predefinidas ficarão iluminadas em verde.
3. Excluir todas as macros: pressione e segure FN2 + "Backspace" por cinco segundos para apagar todas as macros.

Dúvidas frequentes

1. Se o teclado não responder, verifique se o cabo USB do teclado está inserido corretamente na porta USB correspondente, ou experimente outra porta USB no computador.
2. Se ocorrer o derramamento de líquido sobre o teclado, remova imediatamente o cabo USB que liga o teclado ao computador. Seque o excesso de líquido e deixe o teclado em um local aquecido (por exemplo, sob uma lâmpada) para deixar que seque naturalmente antes de utilizá-lo novamente.

REDRAGON QUALITY ASSURED

型号	红龙K617-R/8562		备注： 尺寸：100x100mm (风琴折页) 材质：80g书写纸 印刷：单黑色双面印刷				
名称	说明书						
日期	2021-7-2						
页码	1 OF 1		文件编号				
绘图	雷国建	审核		核准		版本	A.0

Eastern times Tech

TM.by ONLINE STORE
https://tm.by
Интернет-магазин