

1

CABINET INTERNAL WIDTH
CABINET DEPTH

* Determine the cabinet internal width and depth before starting the design of drawer.

2

DIW = Drawer Internal Width
CIW = Cabinet Internal Width
DD = Drawer Depth
NL = Nominal Length

* Install the drawer according to the dimensions above.

3

* Drill the slide mounting holes. (Use the Smart Drilling Jig with ruler or Smart Drilling Jig in order to work of drawer properly.)

4

* Mounting hole axes were given above according to length of slide

5

* Slider hole axes can be drilled by using Smart Drilling Jig.

6

* Screw the slider to the cabinet from the holes shown in figure with chipboard screw Ø3.5x16.

7

* Drill the Smart lock fixing holes and drawer back holes by using lock template.

8

* Use angled holes to mount smart lock when wooden floor width is selected less than 12 mm.

9

* Pull the "C" handle to displace drawer. Use "B" nut to adjust left-right and "A" nut to adjust up and down.

10

* Drawer can be displaced by pulling the "C" handle.