

Einbauanleitung

Fitting instructions

Istruzioni di montaggio

Notice de montage

Instrucciones de montaje

Monteringsanvisning

CORTECO

80000063

80000064

BMW 1er/1 series (E81-E87)

09.04 →

BMW 1er/1 series (E82) Coupe

10.07 →

BMW 1er/1 series (E88)

03.08 →

BMW 3er/3 series (E90;E91)

01.05 →

BMW X1 (E84)

10.09 →



The Perfect Change.

< 10 min

