

Einbauanleitung

Fitting instructions

Istruzioni di montaggio

Notice de montage

Instrucciones de montaje

Monteringsanvisning

CORTECO

80001189

80001190

Chrysler Dodge Avenger

06.07 →

Chrysler Dodge Caliber

06.06 →

Chrysler Dodge Journey

06.08 →

Chrysler Jeep Compass

08.06 →

Chrysler Jeep Patriot

01.08 →

Fiat Freemont

08.11 →

Lancia Flavia Cabrio

03.12 →



The Perfect Change.

