

Einbauanleitung

Fitting instructions

Istruzioni di montaggio

Notice de montage

Instrucciones de montaje

Monteringsanvisning

CORTECO

80001189

80001190



The Perfect Change.

Chrysler Dodge Avenger
Chrysler Dodge Caliber
Chrysler Dodge Journey
Chrysler Jeep Compass
Chrysler Jeep Patriot
Fiat Freemont
Lancia Flavia Cabrio

06.07 →
06.06 →
06.08 →
08.06 →
01.08 →
08.11 →
03.12 →

