

Einbauanleitung

Fitting instructions

Istruzioni di montaggio

Notice de montage

Instrucciones de montaje

Monteringsanvisning

CORTECO

Chevrolet Cruze (J300)
Chevrolet Volt
Chevrolet Malibu
Chevrolet Orlando
OPEL Ampera
OPEL Astra J + Sports Tourer
OPEL Insignia
OPEL Meriva B
OPEL Mokka
OPEL Zafira III

80001185

80001186

05.09. →

11.11. →

01.12. →

12.10. →

11.11. →

12.09. →

07.08. →

06.10. →

06.12. →

01.11. →



The Perfect Change.

10-20 min

