




Disney

43191






2



1




2




3



3




1



4




2



5




3



6



4



7




1x



1x

5



8



1x



1x

6



9



7



10



8



11



1x

9



12



10



13



2x

11



14



2x

12




1x

13




15


14



16




15



17



16



18

1x
4600294

2x
6210272

1x
6332638

2x
6293665

1x
370001

1x
6332664

2x
6313138

4x
4249112

1x
4234525

1x
6335114

1x
6332634

2x
6092203

1x
6249584

2x
6166107

1x
6247798

1x
6055639

1x
6335309

1x
6294227

2x
4213568

1x
4159739

4x
4550323

2x
6269992

1x
6055640

1x
6056851

1x
6274729

1x
6264989

3x
6244910

1x
6244885

1x
6248206

1x
416201

1x
6249095

2x
6296050

1x
6332460

1x
6226644

1x
6300588

2x
6102537

1x
6342511

1x
6058368

2x
6332629

2x
6213786

19


1x
6240042


1x
6146223


1x
6034676


1x
4211421


2x
4211045


1x
6056226


1x
6254219


2x
6209673


1x
6296485


2x
6061201


2x
6206151


1x
6172421


3x
6217794


2x
6268863


1x
6263792


2x
6133062


2x
6122543


1x
6296493


1x
6249064


1x
6332647


1x
6332642


1x
6334786


2x
6162580


4x
4529247


1x
6330618


1x
6173109


1x
6038163


1x
6075079


1x
6107194


4x
6207933


1x
6009771


2x
6172437


2x
4536675


1x
6270116


2x
6312473


1x
6278548

Customer Service

Kundenservice

Service Consommateurs

Servicio Al Consumidor

[LEGO.com/service](https://www.lego.com/service) or dial



00800 5346 5555 :



1-800-422-5346 :

