

Quick Start Guide

Pan/Tilt Home Security Wi-Fi Camera





STEP 1

DOWNLOAD APP

Get the **Tapo** app from the Apple App Store or Google Play.







LED Indication

Solid Red Starting up.

Solid Green

Connected to Wi-Fi.

Blinking Red Camera resetting. Blinking Red and Green Ready for setup.

Blinking Green Slowly Connecting to Wi-Fi.

Blinking Green Quickly Camera updating.

Mounting Kit







Mounting Template







Anchors (for wall mounting)



POWER UP

Plug in your camera and wait until the LED blinks red and green.



STEP 3

SET UP

Tap the (+) button in the app and select Smart Camera C200. Follow app instructions to complete setup.





Mounting Instructions

1. Mark Position

Place the mounting template where you want the camera. For wall mounting, drill two holes through two circles.



2. Mount Base

Affix the camera base using the screws

For wall mounting, insert two anchors into the holes and use the screws to affix the camera base over the anchors.



3. Secure Camera

Attach the camera on the base and rotate to secure the camera.



Appearance


Tilt the camera lens up to find the RESET button and the microSD card slot.

RESET Button

While the camera is powered on, press and hold the RESET button for at least 5 seconds until the LED blinks red. The camera will reset and reboot.

microSD Card Slot

Insert a microSD card and initialize it on the app for local recording.





For technical support, the user guide and more information, please visit www.tapo.com/support/



- . Keep the device away from water, fire, humidity or hot environments.
- . Do not use damaged charger or USB cable to charge the device.
- Do not use any other chargers than those recommended.
- . Do not use the device where wireless devices are not allowed.
- Adapter shall be installed near the equipment and shall be easily accessible.
- . Use only power supplies which are provided by manufacturer and in the original packing of this product. If you have any questions, please don't hesitate to contact us,
- . Do not disassemble, repair or modify the product.
- Do not use the product if the casing has been broken. Danger of electric shock.
- . Never touch the product with wet hands.
- . Do not place near automatically controlled devices such as fire alarms. Radio waves emitted from this product may cause such devices to malfunction resulting in an accident.
- Observe restrictions on using wireless products in fuel depots, chemical plants or
- . Do not use liquid to clean the product. Only use a dry cloth.
- Never put metal objects inside the product. If a metal object enters the product turn off the circuit breaker and contact an authorised electrician.
- This product is not intended to be used when providing medical care. Consult the manufacturer of any personal medical devices, such as pacemakers or hearing aids to determine if they are adequality shielded from external RF (radio frequency) energy.
- . Do not use this product in health care facilities. Hospitals or health care facilities may
- be using equipment that could be sensitive to external RF energy. . Do not use this product near water for example near a bath tub, wash bowl, kitchen
- sink or laundry tub, in a wet basement or near a swimming pool. . The product should be kept free from excessive smoke, dust or high temperature and

- When you leave the product unused for a long time unplug the product from the
- . Product should be kept away from heat sources such as radiators, cookers etc. it greater than 40 degrees. Damp basements should also be avoided.
- This product may interfere with other electronic products such as TV. radios, personal. computers, phones or other wireless devices.
- Operating Temperature: 0 °C ~ 40°C (32°F ~ 104°F)

Please read and follow the above safety information when operating the device. We cannot guarantee that no accidents or damage will occur due to improper use of the device. Please use this product with care and operate at your own risk.

©2020 TP-Link

