


cersanit



www.cersanit.com

PL instrukcja montażu

LT montavimo instrukcija

LV montāžas instrukcija

RU инструкция по монтажу

UK інструкція по монтажу

SK návod na montáž

FR mode d'emploi

CZ návod na montáž











DE anleitung

EN instructions for assembly


ET paigaldusjuhend

HU szerelési útmutató


RO instrucțiuni de montaj



1





2



3



A



B


C1

C2




4


4



B




C1 C2



5



5

| | |
|----|----|
| A | B |
| C1 | C2 |




6

A




6




B

C2



C1





Cersanit S.A.
Al. Solidarności 36, 25-323 Kielce
tel. 41 / 315 80 04, fax 41 / 315 80 06
www.cersanit.com