



Einhell

EXPERT

POWER X-CHANGE

Robot Lawn Mower

FREELEXO

Item No.: 3413940

Ident No.: 21020

Bar Code: 4006825646764

The Einhell FREELEXO robot lawnmower from the Power X-Change series can be combined with all system batteries. The FREELEXO is controlled via app or the intuitive keypad. The operating time of the FREELEXO can be precisely programmed to the specific day. To protect it from theft the lawn robot has PIN code protection and a warning signal. It automatically returns to and gets charged up by the charging unit. Using the multi-zone mowing mode, this robot lawnmower is even suitable for complex gardens. The safety sensor system has impact, tilt and lift sensors. There is also an integrated rain sensor. The robot lawnmower has a cutting height adjustment facility between 20 mm and 60 mm and is suitable for inclines up to 35%.


Features & Benefits

- PXC system battery - can also be used for other PXC products
- App using Bluetooth - user-defined robot lawnmower control
- Multi area mowing - for complex gardens
- Intuitive keypad
- Programmable operating time for each specific day
- Safety sensor system thanks to impact, tilt and lift sensors
- Anti-theft protection in form of PIN code and warning signal
- Rain sensor
- Cutting height adjustment (20-60mm)
- Suitable for slopes up to 35%
- Carry-handle for comfortable transport
- Automatic return to charging unit and charging
- Supplied without battery and charger (available separately)



Technical Data

- Power 18 V
- Accumulator 18 V | 0 mAh | Li-Ion
- Cutting width 18 cm
- Slope 35 %
- Cutting height adjustment Continuously 20-60 mm
- Recommended area 0 m²
- Perimeter wire 0 m
- Hooks 0 Pieces
- Spare blades No
- Connecting clamps 0 Pieces



Logistic Data

- Product weight (kg) 12.45
- Gross weight (kg) 16
- Dimensions single packaging 730 x 516 x 320 mm
- Pieces per export carton 1 Pieces
- Gross weight of export carton 16 kg
- Dimensions export carton 733 x 515 x 325 mm
- Container quantities (20"/40"/40"HC) 236 | 495 | 566



Illustrations can contain accessories, which are not included in standard extent of delivery
 Illustration similar (in design), production-wise modifications reserved
 GS mark belongs to the product itself only, excluded accessory
 Generated at: 29.10.2020 13:58
 Page 1

Available as special accessories



Power X-Boostcharger 6A
Charger
Item No.: 4512064
Bar Code: 4006825629019
Einhell Accessory



18V 3,0Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



Installation Kit 800m2
Robot Lawn Mower Accessory
Item No.: 3414011
Bar Code: 4006825646870
Einhell Accessory



2x 3,0Ah & 30min PXC Kit
PXC-Starter-Kit
Item No.: 4512098
Bar Code: 4006825646986
Einhell Accessory



18V 4,0Ah Power X-Change
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



18V 4,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



Begrenzungsdraht 50 m
Robot Lawn Mower Accessory
Item No.: 3414021
Bar Code: 4006825648782
Einhell Accessory



Befestigungshaken 100 Stk
Robot Lawn Mower Accessory
Item No.: 3414023
Bar Code: 4006825648805
Einhell Accessory



Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



2x 18V 4,0Ah PXC-Twinpack
Battery
Item No.: 4511489
Bar Code: 4006825638578
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



18V Battery Charger 3,0A - PXC
Charger
Item No.: 4514095
Bar Code: 4006825655292
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack
Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



2x 3,0Ah & Twincharger Kit
PXC-Starter-Kit
Item No.: 4512083
Bar Code: 4006825638509
Einhell Accessory



18V 4-6Ah Multi-Ah PXC Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210
Einhell Accessory



Installation Kit 500m2
Robot Lawn Mower Accessory
Item No.: 3414010
Bar Code: 4006825646863
Einhell Accessory



Installation Kit 1200m2
Robot Lawn Mower Accessory
Item No.: 3414012
Bar Code: 4006825646887
Einhell Accessory



18V 2,0Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



18V 3,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512041
Bar Code: 4006825613698
Einhell Accessory



Ersatzklingen 12 Stk
Robot Lawn Mower Accessory
Item No.: 3414020
Bar Code: 4006825648775
Einhell Accessory



Verbindungsklemmen 4 Stk
Robot Lawn Mower Accessory
Item No.: 3414022
Bar Code: 4006825648799
Einhell Accessory



18V 2,5Ah Power X-Change
Battery
Item No.: 4511516
Bar Code: 4006825650518
Einhell Accessory



18V 5,2Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



2x 18V 2,5Ah PXC-Twinpack
Battery
Item No.: 4511518
Bar Code: 4006825651676
Einhell Accessory



Mähroboter Garage
Robot Lawn Mower Accessory
Item No.: 3414024
Bar Code: 4006825654417
Einhell Accessory

2x 18V 2,5Ah PXC-Twinpack CB
Battery
Item No.: 4511524
Bar Code: 4006825656206
Einhell Accessory

Illustrations can contain accessories, which are not included in standard extent of delivery

Illustration similar (in design), production-wise modifications reserved

GS mark belongs to the product itself only, excluded accessory

Generated at: 29.10.2020 13:58

Page 2