



1	开关罩Switch instruction
2	开关switch
3	碳刷Carbon brush
4	转子rotor
5	定子stator
6	轴承Bearing
7	塑料风叶Plastic fan
8	左机壳Left housing
9	支架Stand
10	偏心轴The eccentric shaft
11	偏心块Eccentric
12	挡风罩Cover plate
13	底板Work base plate
14	钢丝夹Paper clamp
15	泡沫垫Foam pad
16	螺丝Screw
17	轴承Bearing
18	碳刷Carbon brush
19	右机壳Right housing
20	螺丝Screw
21	电源线Power cord
22	电容Capacitance
23	压线板Cable clamp
24	护线套Wire cover
25	接线柱Terminal block
26	集尘支架dust collection trestle
27	集尘袋dust collection bag
28	轴承Bearing
29	钢丝夹Paper clamp
30	

230V 1.8A 新手掌砂