

RU ПАСПОРТ И РУКОВОДСТВО ПО ЭКСПЛУАТАЦИИ

**! ВАЖНО, СОХРАНЯТЬ ДЛЯ
ПОСЛЕДУЮЩИХ КОНТАКТОВ.
ВНИМАТЕЛЬНО ПРОЧТИТЕ.**



Кресло складное (садовое)


арт. 42-555401
арт. 42-555402
арт. 42-555403




Комплектность	шт.
Кресло складное	1
Руководство по эксплуатации, инструкция	1
Упаковка	1

Инструкция по сборке:

1. Чтобы разложить кресло растяните крепления у вершины стула в разные стороны.



2. Чтобы сложить кресло, притяните крепления у сидения и спинки стула друг к другу.



Назначение:

Кресло складное влагостойкое предназначено для использования в качестве индивидуальной трансформируемой мебели для отдыха сидя на открытом воздухе и в помещениях.

Правила эксплуатации:

- Максимальная нагрузка на кресло 120 кг. Превышение допустимой нагрузки может привести к поломке кресла.
- Во избежание несчастных случаев не раскачивайтесь на кресле и не используйте кресло одновременно двумя лицами.
- При складывании и раскладывании, во избежание защемления, не допускается нахождение рук между подвижными частями кресла.
- Использовать изделие необходимо при температуре воздуха от +2...+25°C и относительной влажности воздуха 45-70%.
- При установке изделия в непосредственной близости от нагревательных и отопительных приборов поверхность во время эксплуатации должна быть защищена от нагрева.

- Температура нагрева элементов мебели не должна превышать +40°C.
- При эксплуатации необходимо исключить попадание воды и иных жидкостей на элементы изделия, соприкасающиеся с полом.

Хранение и уход:

- Хранить кресло необходимо в сухом помещении при температуре +2...+25 °C при относительной влажности 45-70%.
- Кресло должно использоваться на горизонтальной поверхности в устойчивом положении.
- По мере загрязнения используйте мягкие моющие средства и обильно смывайте их водой.
- Просушивайте кресло в разложенном виде на открытом воздухе или в помещении.
- Во время транспортировки кресло должно находиться в сложенном состоянии.



Не допускается:

- Использовать кресло не по назначению.
- Вставать на кресло ногами.
- Оставлять детей в кресле без присмотра.
- Разрешать детям самостоятельно производить складывание или раскладывание кресло.
- Ставить кресло близко к открытому огню.
- Хранить и перевозить кресло вместе с острыми предметами.

СРОК СЛУЖБЫ-3 ГОДА

Производитель оставляет за собой право вносить в конструкцию и внешний вид изменения, не ухудшающие качества изделия.

Возврат товара не производится:

- По истечению гарантийного срока.
- В случае нарушения правил эксплуатации мебели, указанных в руководстве по эксплуатации.
- В случае несоблюдения требований инструкции по сборке.
- Если изделие имеет следы постороннего вмешательства и ремонта.
- При внесении потребителем изменений в конструкцию изделия.
- При преднамеренном повреждении, неправильном обхождении, повреждении домашними животными, повреждении повышенной температурой и огнем, превышении допустимых нагрузок на элементы мебели, указанные в руководстве по эксплуатации.
- Мебель повреждена животными или химическими реагентами.

Дефектами мебели не являются:

- Незначительное отличие в оттенке обивочных материалов.
- Скрип в механизмах трансформации.
- Морщины на облицовочном материале мягких элементов.
- Потертости мебельной обивки из ткани возникающие при эксплуатации мебели в местах, находящихся под нагрузкой, а также на выступающих элементах.

Обязательства выполняются согласно действующему законодательству Республики Беларусь.

Гарантия недействительна, если вы нарушили правила эксплуатации мебели.

Для того, чтобы иметь возможность воспользоваться гарантийным обеспечением, необходимо сохранять все сопроводительные документы.



Внимание!

Паспорт следует хранить в течение всего срока службы изделия.

Изготовитель: "SKIPFIRE LIMITED", Romanou, 2, Tlais Tower, 6th floor, flat/Office 601 P.C.1070, Nicosia, Cyprus. Кипр. Страна производства: Китай. Импортер в Республике Беларусь: ООО «ДК Комплект», 220103, г. Минск, ул. Кирова, 50, кв. 302А. Импортер в Российской Федерации: ООО «Садовая техника и инструменты», 105082, г. Москва, ул. Большая Почтовая, дом 40, строение 1, этаж 3, комната 7А. Телефон для обращений потребителей в Республике Казахстан: +7 778 8540843. Гарантийный срок эксплуатации: 18 месяцев со дня продажи конечному потребителю, при условии соблюдения условий транспортирования, хранения и эксплуатации.



EN PASSPORT AND INSTRUCTION FOR USE

**! IMPORTANT, SAVE FOR FUTURE
• CONTACTS. READ CAREFULLY.**


Folding chair

item no. 42-555401
item no. 42-555402
item no. 42-555403




Instructions for assembly:

1. To unfold the chair stretch the fasteners at the top of the chair in different directions.



2. To fold the chair, pull the fasteners at the seat and back of the chair to each other.



Purpose:

Waterproof folding chair is designed for use as individual transformable outdoor and indoor seating furniture.

Rules of operation:

- The maximum load of the chair is 120 kg. Exceeding the permissible load may lead to breakage of the chair.
- To avoid accidents do not rock on the chair and do not use the chair with two persons at the same time.
- When folding and unfolding, do not put your hands between the moving parts of the chair to avoid pinching.
- The product should be used at an air temperature of +2...+25°C and a relative humidity of 45-70%.
- When installing the product in the immediate vicinity of heating and heating devices, the surface must be protected from heat during operation.
- The temperature of the furniture elements must not exceed +40°C.
- During operation, it is necessary to avoid water and other liquids in contact with the elements of the product that are in contact with the floor.



Storage and care:

- The armchair should be stored in a dry room at +2 ... +25°C with relative humidity of 45-70%.
- The armchair should be used on horizontal surface in stable position.
- As far as dirtiness is concerned use mild detergents and wash it off generously with water.
- Dry the chair when it is unfolded in the open air or indoors.
- The chair must be in the folded position during transport.

⚠ Do not:

- Use the chair for purposes other than its intended use.
- Stand on the chair with legs on the floor.
- leave children in the chair without supervision.
- leave the child seat unattended, allow children to fold the seat in or out on their own.
- Put the armchair close to an open fire.
- Store and transport the dental chair together with sharp objects.

SERVICE LIFE-3 YEARS

The warranty period is calculated from the date of sale, if the date of sale, certified by a stamp of the sales organization, is present in the passport.

No returns are available:

- On the expiry of the warranty period.
- In case of violation of the rules of furniture operation, specified in the instruction manual.
- If the product does not comply with the assembly instructions.
- If the product has traces of tampering and repair.
- If the consumer has made changes to the product design.
- In case of intentional damage, mishandling, damage by pets, heat and fire damage, exceeding the allowable loads on the furniture elements specified in the operating manual.
- The furniture has been damaged by animals or chemicals.

Furniture is not defective:

- Slight difference in shade of upholstery materials.
- Creaking in the transformation mechanisms.
- Wrinkles in the lining material of upholstered elements.
- Rubbing of furniture upholstery fabric arising from the use of the furniture in areas under stress and on protruding elements.

The obligations are fulfilled in accordance with the current legislation of the Republic of Belarus.

The warranty is not valid if you have violated the rules of operation of the furniture.
In order to be able to take advantage of the warranty, you must keep all the accompanying documents.

⚠ Warning!

The data sheet should be kept for the entire service life of the product.

Manufacturer: "SKIPFIRE LIMITED", Romanou, 2, Tlais Tower, 6th floor, flat/Office 601 P.C.1070, Nicosia, Cyprus. Country of origin: P.R.C. Importer in the Republic of Belarus: "TD Komplekt" LLC, 50 Knorina str., 302A, Minsk, 220103. Importer in the Russian Federation: LLC "Garden equipment and tools", 105082, Moscow, Bolshaya Pochtovaya street, 40, building 1, floor 3, room 7A, Telephone number for consumers in the Republic of Kazakhstan: +7 778 8540843.

