


cersanit



RU инструкция по монтажу и эксплуатации настенных смесителей

PL instrukcja montażu i obsługi baterii ściennych

EN installation and operation manual for wall-mounted faucets

KK qabyrgalyq aralastyrgyshtarğa arналған montajday jáne eksplýatatsiia boiynsha nusqaylyq

AZ divardan asılan su kranlarının quraşdırılması və istismarı üzrə təlimat

UZ devorga ilinadigan smesitellarni o'rnatish va foydalanish bo'yicha yo'riqnom

KG yubalga asma chabyshyrgynty ornottu jana ishettuu boюнча нускама

KA გედლის შემზღვის მონტაჟის და ექსპლუატაციის ინსტრუქცია

TK diwar garyjylary gurnamak we ulanmak boiynça gözükdirme


HY մասն ձորակների տեղադրման և շահագործման հրահանգ

TL dastramall oıd ba nasbukni va istifodabariı omextakunandaıon devorıı


MN ханын ус холигч угсрах ба ашиглах заавар



14mm/30mm/27mm



2.5mm



M24*1

