

**LEGO**

**CITY**

60277





- 1** Scan the code on the front cover  
Scanne den Code auf der Titelseite  
Scanne le code sur la page de couverture  
Scanner le code sur la page couverture  
Scansiona il codice sulla copertina  
Escanea el código de la portada  
Faz scan do código na frente da capa  
Olvasd be a borítón látható kódot!  
Noskenë kodu uz priekšējā vāka  
扫描封面上的二维码





- 2** Get Instructions PLUS  
Hol dir Instructions PLUS  
Obtiens les instructions PLUS  
Obtenir les Instructions PLUS  
Scarica Instructions PLUS  
Descubre Instructions PLUS  
Obtém Instruções PLUS  
Szerezd be az Instructions PLUS kiegészítőt!  
Sanem "Instructions PLUS"  
获取更多说明

**LEGO.com/apps**


Check for compatibility  
Kompatibilität prüfen  
Vérifier la compatibilité  
Controlla la compatibilità  
Comprueba tu compatibilidad


Verificar a compatibilidade  
Ellenőrizd a kompatibilitást  
Pārbaudīt saderību  
检查兼容性





4





6



1



2





2x

3




8






4




5





1x

6



10



2x

7



1x

8





2x

9



12



10



13



1



14



**2**



**3**





1x

4




16






5




6






2x



7



18



8



9






1x




1x


10




20



11



12




21



2x


13




22



14



15



23




2x



2x

# 16




24






2x

17



2x

18




25



2x


19




26



20




21



27




22




28



23




24






1x

25



30

26



31







# CITY ADVENTURES

City Abenteuer  
Aventuras en City  
City Aventuras  
City kalandok  
City piedzvojumi  
乐高城市大冒险



VITO  
60242



SAM  
GRIZZLED  
60243



SNAKE  
RATTLER  
60243 · 60276



ROOKY  
PARTNER  
60244



FRANKIE  
LUPELLI  
60244 · 60277



TOM  
BENNETT  
60245



BIG  
BETTY  
60245



WHEELER  
60246



DAISY  
KABOOM  
60246



CLARA  
FIRE CAPTAIN  
60276



GRACIE  
GOODWIN  
60277



DUKE  
TOXMAN  
60242 · 60246 · 60276



FREYA  
MCCLEOD  
60248 · 60280



CLEMMONS  
60247 · 60281



BOB  
60282



FELDMAN  
60282



TREAD  
O'CASE  
60258



HARL  
NUGGS  
60258 · 60266



SHIRLEY  
KEEPER  
60292



MADISON  
60292

# CITY

## ADVENTURES

City Abenteuer  
Aventuras en City  
City Aventuras  
City kalandok  
City piedzīvojumi  
乐高城市大冒险

Aus der erfolgreichen TV-Serie!  
Vu dans la série télévisée à succès !  
Dalla divertentissima serie TV!  
¡De la popular serie de la tele!  
Da série de sucesso da TV!  
A népszerű TV-sorozatból!  
No populārā TV seriāla!  
源自热门动画片!

FROM THE HIT  
TV SERIES!







# CITY



60277



60275



60276

LEGO and the LEGO logo are trademarks of the LEGO Group. ©2021 The LEGO Group. 6354635