

**1**

CABINET INTERNAL WIDTH  
CABINET DEPTH

\* Determine the cabinet internal width and depth before starting the design of drawer.

**2**

DIW = Drawer Internal Width  
CIW = Cabinet Internal Width  
DD = Drawer Depth  
NL = Nominal Length

\* Install the drawer according to the dimensions above.

**3**

\* Drill the slide mounting holes. (Use the Smart Drilling Jig with ruler or Smart Drilling Jig in order to work of drawer properly.)

**4**

\* Mounting hole axes were given above according to length of slide

**5**

\* Slider hole axes can be drilled by using Smart Drilling Jig.

**6**

\* Screw the slider to the cabinet from the holes shown in figure with chipboard screw Ø3.5x16.

**7**

\* Drill the Smart lock fixing holes and drawer back holes by using lock template.

**8**

\* Use angled holes to mount smart lock when wooden floor width is selected less than 12 mm.

**9**

\* Pull the "C" handle to displace drawer. Use "B" nut to adjust left-right and "A" nut to adjust up and down.

**10**

\* Drawer can be displaced by pulling the "C" handle.