



ENGLISH

ELECTRIC APPLIANCE FOR HEATING LIQUIDS (KETTLE) VT-7039 ST

The liquid heating appliance (kettle) is intended for boiling drinking water only.

DESCRIPTION

1. Kettle body
2. Kettle spout
3. Lid
4. Lid opening button
5. Handle
6. Water level scale
7. ON/OFF button -0/I-
8. Base
9. Cord storage

ATTENTION!

For additional protection it is reasonable to install a residual current device (RCD) with nominal operation current not exceeding 30 mA, to install RCD, contact a specialist.

NOTES:

Before using the kettle, make sure that the on/off button (7) is not blocked by any foreign objects, and the lid (3) is tightly closed, otherwise auto switch off the kettle is not possible.

Before removing the kettle from the base, make sure that the kettle is switched off (the on/off button (7) is in the upper position -0).

To avoid burns by hot steam, do not bend over the kettle spout (2) while it is operating.

Safety measures

Before using the unit, read this manual carefully and keep it for future reference.

Use the unit for intended purposes only, as specified in this manual.

Mishandling the unit can lead to its breakage and cause harm to the user or damage to his/her property.

• Use the unit for its intended purpose only and in strict accordance with the instructions.

• Make sure that your home mains voltage corresponds to the voltage specified on the unit body.

• The power cord is equipped with a «grounding» plug; plug it into the socket with a reliable grounding contact.

• To avoid the risk of fire, do not use adapters for connecting the kettle to the mains.

• Do not use the kettle in bathrooms. Do not use it near swimming pools or other containers filled with water.

• Do not use the kettle near heat sources or open flame.

• Do not use the unit in places where aerosols are sprayed or highly flammable liquids are used.

• Do not use the kettle outdoors.

• Do not leave the operating kettle unattended.

• Place the kettle on a flat stable surface; do not place the kettle on the edge of the table.

• When removing the kettle from the base (6), make sure that it is switched off (the button (7) is in the upper position -0).

• After switching the kettle off, wait for 10-20 seconds, then you can switch it on again for re-boiling.

• If you accidentally switch the kettle on, but the water level appears to be below the minimal mark, the automatic thermal switch will be on and the kettle will be switched off automatically.

In this case take the kettle from the base (8), let it cool down for 10-15 minutes, then fill it with water and switch it on, the kettle will operate in normal mode.

Note:

• There is the cord storage (9) on the reverse side of the base (8). You can adjust the optimal power cord length by folding it in the cord storage in a corresponding way.

CLEANING AND CARE

• Before cleaning disconnect the unit from the mains, pour out water and let the kettle cool down.

• Wipe the outer surface of the kettle with a damp cloth or a sponge. Use soft detergents to remove dirt; do not use metal brushes and abrasive detergents.

• Do not immerse the kettle and the base into water or any other liquids.

• Do not touch the power cord and the power plug with wet hands.

• Do not switch the kettle on if it is empty.

• Do not fill the kettle with water when it already stands on the base.

• Do not use the kettle if the lid is not closed tightly.

• Take the kettle off the base before opening the lid.

• Use the kettle only for boiling drinking water, do not heat oil or any other liquids.

• Ensure that the water level in the kettle is not below the minimal mark -MIN- and not above the maximal mark -MAX-. If the water level reaches the maximal mark, boil water can splash out of the kettle during boiling.

• To avoid burns by hot steam, do not bend over the kettle spout while it is operating.

• Do not open the kettle while water is boiling.

• Do not touch hot surfaces of the kettle, take it only by the handle.

• Be careful while carrying the kettle filled with boiling water.

• Do not remove the operating kettle from the base. If you need to take the kettle off, switch it off first, setting the on/off button to the position -0- and then remove it from the base.

• Unplug the kettle before cleaning and when you are not using the kettle. Never pull the power cord when disconnecting the kettle from the mains; take the power plug and carefully remove it from the mains socket.

• To avoid electric shock, do not immerse the unit and the base into water or any other liquids.

• Do not wash the kettle and the base in a dishwashing machine.

• Place the unit out of reach of children during the operation and cooling down.

• Do not allow children to touch the unit body and the power cord during the unit operation.

• The unit is not intended for usage by physically or mentally disabled persons (including children) or for persons lacking experience or knowledge, if they are not under supervision of a person who is responsible for their safety or if they are not instructed by this person on the usage of the unit.

• Do not leave children unattended to prevent using the unit as a toy.

• For children safety reasons do not leave polyethylene bags, used as packaging, unattended.

Attention! Do not allow children to play with polyethylene bags or packing film. Danger of suffocation!

• Check the power cord and the power plug and the kettle body integrity periodically.

• Never attempt to repair the unit if the power cord or the power plug is damaged, if the kettle works improperly or after it was dropped.

• Do not attempt to repair the unit. Do not disassemble the unit by yourself, if any malfunction is detected or after it was dropped, unplug the kettle and apply to any authorized service center from the contact address list given in the warranty certificate and on the website www.vitek.ru.

• Transport the unit in the original package only.

• For environment protection do not throw the unit with usual household waste after its service life expiration; apply the specialized center for further recycling.

• Keep the unit out of reach of children and disabled persons.

THE UNIT IS INTENDED FOR HOUSEHOLD USAGE ONLY

BEFORE THE FIRST USE

After unit transportation or storage at low temperature keep it for at least three hours at room temperature before switching on.

There may be water spots in the kettle, this is normal, as the unit has undergone factory quality control.

- Unpack the kettle and remove any stickers that can prevent unit operation .

- Check the unit for damages; do not use it in case of damages.

TECHNICAL SPECIFICATIONS

Power supply: 220-240 V - 50 Hz

Power consumption: 1850-2200 W

Maximum water capacity: 1.7 L

The manufacturer preserves the right to change the specifications of the units without a preliminary notification

Unit operating life is 3 years

Guarantee

Details regarding guarantee conditions can be obtained from the dealer from whom the appliance was purchased. The bill of sale or receipt must be produced when making any claim under the terms of this guarantee.

THE UNIT IS INTENDED FOR HOUSEHOLD USAGE ONLY

BEFORE THE FIRST USE

After unit transportation or storage at low temperature keep it for at least three hours at room temperature before switching on.

There may be water spots in the kettle, this is normal, as the unit has undergone factory quality control.

- Unpack the kettle and remove any stickers that can prevent unit operation .

- Check the unit for damages; do not use it in case of damages.

THE UNIT IS INTENDED FOR HOUSEHOLD USAGE ONLY

PERIODIC INSPECTION

After unit transportation or storage at low temperature keep it for at least three hours at room temperature before switching on.

There may be water spots in the kettle, this is normal, as the unit has undergone factory quality control.

- Unpack the kettle and remove any stickers that can prevent unit operation .

- Check the unit for damages; do not use it in case of damages.

THE UNIT IS INTENDED FOR HOUSEHOLD USAGE ONLY

PERIODIC INSPECTION

After unit transportation or storage at low temperature keep it for at least three hours at room temperature before switching on.

There may be water spots in the kettle, this is normal, as the unit has undergone factory quality control.

- Unpack the kettle and remove any stickers that can prevent unit operation .

- Check the unit for damages; do not use it in case of damages.

THE UNIT IS INTENDED FOR HOUSEHOLD USAGE ONLY

PERIODIC INSPECTION

After unit transportation or storage at low temperature keep it for at least three hours at room temperature before switching on.

There may be water spots in the kettle, this is normal, as the unit has undergone factory quality control.

- Unpack the kettle and remove any stickers that can prevent unit operation .

- Check the unit for damages; do not use it in case of damages.

THE UNIT IS INTENDED FOR HOUSEHOLD USAGE ONLY

PERIODIC INSPECTION

After unit transportation or storage at low temperature keep it for at least three hours at room temperature before switching on.

There may be water spots in the kettle, this is normal, as the unit has undergone factory quality control.

- Unpack the kettle and remove any stickers that can prevent unit operation .

- Check the unit for damages; do not use it in case of damages.

THE UNIT IS INTENDED FOR HOUSEHOLD USAGE ONLY

PERIODIC INSPECTION

After unit transportation or storage at low temperature keep it for at least three hours at room temperature before switching on.

There may be water spots in the kettle, this is normal, as the unit has undergone factory quality control.

- Unpack the kettle and remove any stickers that can prevent unit operation .

- Check the unit for damages; do not use it in case of damages.

THE UNIT IS INTENDED FOR HOUSEHOLD USAGE ONLY

PERIODIC INSPECTION

After unit transportation or storage at low temperature keep it for at least three hours at room temperature before switching on.

There may be water spots in the kettle, this is normal, as the unit has undergone factory quality control.

- Unpack the kettle and remove any stickers that can prevent unit operation .

- Check the unit for damages; do not use it in case of damages.

THE UNIT IS INTENDED FOR HOUSEHOLD USAGE ONLY

PERIODIC INSPECTION

After unit transportation or storage at low temperature keep it for at least three hours at room temperature before switching on.

There may be water spots in the kettle, this is normal, as the unit has undergone factory quality control.

- Unpack the kettle and remove any stickers that can prevent unit operation .

- Check the unit for damages; do not use it in case of damages.

THE UNIT IS INTENDED FOR HOUSEHOLD USAGE ONLY

PERIODIC INSPECTION

After unit transportation or storage at low temperature keep it for at least three hours at room temperature before switching on.

There may be water spots in the kettle, this is normal, as the unit has undergone factory quality control.

- Unpack the kettle and remove any stickers that can prevent unit operation .

- Check the unit for damages; do not use it in case of damages.

THE UNIT IS INTENDED FOR HOUSEHOLD USAGE ONLY

PERIODIC INSPECTION

After unit transportation or storage at low temperature keep it for at least three hours at room temperature before switching on.

There may be water spots in the kettle, this is normal, as the unit has undergone factory quality control.

- Unpack the kettle and remove any stickers that can prevent unit operation .

